




**DIAGRAM 4**



Key to dimensions / mm						
	A	B	C	D	E	F
SURFACE MOUNT	208	255	100Ø	127	69	N/A
FLUSH MOUNT	208	255	100Ø	127	69	225

4

**HUMIDITY ADJUSTMENT**  
To adjust humidity and timer  
remove front cover and the timer cover



- TIMER CONTROL ADJUSTMENT**
- 1) Turn anti-clockwise to reduce time setting. Minimum time is 30 seconds.
  - 2) Turn clockwise to increase time setting. Maximum time is 30 mins.
- HUMIDITY SENSOR ADJUSTMENT**
- 1) Turn anti-clockwise to increase sensitivity e.g. fan will stay on most of time (49-50%Rh)
  - 2) Turn clockwise to reduce sensitivity e.g. fan will not switch on until humidity is very high (90-100%Rh)

**TIMER ADJUSTMENT**



The 100 fan with a time delay fitted will run approximately one minute after it has been switched off. This time delay can be increased by firstly switching off the power to the fan. Remove front cover and the timer cover as detailed. Insert a small screwdriver into the slot marked (1). Turn clockwise to reduce the time and anti-clockwise to increase the time. (For CF-100 range adjust by turning thumb wheel) **Only adjust with power switched off.**  
The minimum time the timer will run for is 20 seconds and the maximum is approx 20 minutes.

5

**IMPORTANT USER MAINTENANCE NOTES**


When carrying out any maintenance on the fan always isolate the mains power supply, if in doubt contact a qualified electrician.  
The fascia of the fan can be removed and cleaned with a damp cloth.  
The fan blade and inside of the chassis can be wiped in position to remove grime and dust, care must be taken not to make the electrical connections wet when cleaning.

**IMPORTANT USER WARNING NOTES**

Switch off mains supply before making any electrical connections. Installation must be supervised by a qualified electrician.  
This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.  
Children should be supervised to ensure that they do not play with the appliance.  
Precautions must be taken to avoid the back-flow of gases into the room from the open fire of gas or other open-flame appliances when mounted in outside windows or walls.

6

077535



0208