

CLEANING

- Always unplug the appliance from the power source before cleaning.
Use a suitable brush to clean the high voltage metal grid and throw away the bodies of insects on the collection tray every week.
The body of the unit should only need occasional wiping over with a damp cloth and mild detergent.

OPERATION

- The unit is switched on and off using the switch in the top left of the fascia.

NOTE: The unit will be hot after use, switch off with care.

Electrical Ratings

Model AVIK20X: Ratings: 220-240V ~ 50/60Hz; 2500V max;
2 x 10W, F4/T5 lamps, consuming 25.7 watts; magnetic transformer;

Model AVIK30X: Ratings: 220-240V ~ 50/60Hz; 2500V max;
2 x 15W, F15/T9 lamps, consuming 37.3 watts; magnetic transformer;

Model AVIK40X: Ratings: 220-240V ~ 50/60Hz; 2500V max;
2 x 20W, F20/T9 lamps, consuming 40 watts; magnetic transformer;

Model AVIK40PX: Ratings: 220-240V ~ 50/60Hz; 2500V max;
2 x 20W, F20/T9 lamps, consuming 43 watts; magnetic transformer;




EXCLUDES
LAMPS



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice

AVIK20X, AVIK30X, AVIK40X insect killers and AVIK40PX Professional insect killers Installation Instructions and User Guide



IMPORTANT SAFEGUARDS

WHEN USING ANY ELECTRICAL APPLIANCE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED.

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE REFERENCE


IF IN ANY DOUBT ABOUT THE INSTALLATION OR USE OF THIS PRODUCT, CONSULT A COMPETENT ELECTRICIAN.




Telephone: **0117 938 6400** Fax: **0117 938 6401**
Victoria Road, Avonmouth, Bristol BS11 9DB
www.addvent.co.uk



Components



Electrical



Installation and use

The AVIK_X insect killers and the AVIK40PX Profesional insect killer are used to attract flying insects and is intended for use in food preparation and manufacturing areas.

WARNINGS

- Check the local voltage before working. As there is a danger of electric shock DO NOT touch the internal high voltage grids. NEVER put metal objects inside the mesh.
- The appliance is for INDOOR USE only, but is NOT SUITABLE for use in barns, stables or similar locations. The appliance is not to be used where there may be flammable vapours or explosive dust.
- Install the appliance out of the reach of children.
- To avoid electric shock, NEVER remove any fixed part of the appliance. DO NOT touch the high-voltage grid with any object when powered.
- If the supply cord, lamp, starter or any other part of appliance is damaged, return the appliance to place of purchase for advice. Repairs should be carried out by the manufacturer or qualified electricians.

INSTALLATION

- **Siting the unit:** The unit should be sited at 90° to the major light source. Ideally, the unit should be mounted as close to 2m from the floor as possible. Avoid mounting in the airstream to prevent dead insect being blown away. DO NOT mount above a food preparation area as the intention is to attract the flying insect away from such areas. To avoid exposure to UV light, the unit should be sited 1m away from any operator workstation.
- **Fixing:** The unit is supplied with suitable fixings for mounting to a wall. Once installed, there should be easy access to the power cord and plug to allow cleaning and maintenance. The unit must be fixed in position before connecting the electricity.
- **Electrical:** This unit MUST be earthed.

MAINTENANCE

- **Replacing the lamps:** Always switch off the electricity before replacing the lamps. Remove the outer cover and mesh. Slide out the lamps, insert replacements and replace mesh and cover. Lamps should be changed annually.